
LITEZUPP INDUSTRIES, LLC

Dashboard LED Installation Instructions

1. Remove top panel of dash
2. Remove plastic surround of steering column
3. Pull dash panel out about one inch to access back of panel
4. Reach in behind dash panel then rotate and remove the four large lamp holders
5. Pull old lamps straight out of the holders.
6. Replace with LED lamps.

Note: The lamp holders must be inserted correctly or they will not light up. (It's a polarity issue) Before replacing the dash panel turn the dash lights **on** to check if they are all working. If not, simply remove the holder of the lamp that is not working and rotate it 180°. Reinsert and it should light up.

7. Reassemble the dashboard